

USER INSTRUCTIONS

Ensemble



Ensemble has been designed with an easy “click” system, which enables quick and simple assembly without the need for tools. This saves time during production, easy shipping and storage or even allows customers to build their chair.

High quality materials allows for a long product life cycle with a warranty of 10 years. At the end its useful life, Ensemble can be returned to the factory, free of charge. In some cases we can even offer a buy back scheme.

Ensemble is available in two colour with a range of ergonomic options and accessories.



Back Height Adjustment



Lift back via integral ratchet system. Lift the back and raise to desired position (six clicks to highest position).

To reduce height, lift back to its highest level, and the back will return to its lowest position.

Seat Height Adjustment | Balance



To raise the seat height lift lever upwards without weight applied. Lever is underneath and towards the front of the seat, on the right hand side. To lower the seat height, apply weight and lift lever.

Back Angle Adjustment | Balance




To adjust back angle independently of the seat, lift the switch on the left hand side under the seat. Push down to lock in position. Leave back unlocked for free float mode to encourage body movement.

Seat Depth Adjustment | Balance



To adjust seat depth push button up and hold to move seat forwards and backwards. Placed underneath the seat on the right hand side, best done when seated.

Arm Options



A Height and Width Adjustable Arms
black or white

B 4D Height and Width Adjustable Arms
black or white

Height: Press and hold button on the outside of arms to raise and lower arms to desired height. Release button to lock in place.

4D: Move arm pads with hands once seated to adjust to preferred position.

Arm Adjustment



Width: Push lever down underneath arm to adjust width. Push lever up to lock into position.